



FALCON Controller


EN	MOUNTING INSTRUCTIONS
BU	ИНСТРУКЦИИ ЗА МОНТАЖ
CZ	POKYNY PRO MONTÁŽ
D	MONTAGEANLEITUNG
DK	MONTERINGSVEJLEDNING
F	INSTRUCTIONS D'INSTALLATION
GR	ΟΔΗΓΙΕΣ ΤΟΠΟΘΕΤΗΣΗΣ
HU	FELSZERELÉSI UTASÍTÁSOK
N	MONTERINGSVEILEDNING
NL	DOKUMENTATIE VAN DE INSTALLATIE
RO	INSTRUCȚIUNI DE MONTAJ
RUS	ИНСТРУКЦИЯ ПО МОНТАЖУ
S	MONTERINGSINSTRUKTIONER
SLOV	NAVODILA ZA MONTAŽO
SR	UPUTSTVO ZA MONTAŽU
TU	MONTAJ KILAVUZU
UKR	ПОСІБНИК З МОНТАЖУ





- 1 Reset
- 2,3,4 CF Card
- 5 USB
- 6,7,8 RS232 3/2/1
- 9 10/100-MB Ethernet
- 10,13,14 LonWorks

- 11 1: 24 Vac $\pm$ 20 %, 19.2 ... 38 Vdc
- 12 2: 0
- 13 3:
- 14 4:
- 15 5,6: LON
- 16 7,8: 24 Vac, max. 2 A
- 17 9,10: 24 Vac, max. 2 A
- 18 11,12: LON
- 19 LEDs







Manufactured for and on behalf of the Environmental and Combustion Controls Division of Honeywell Technologies Sàrl, Rolle, Z.A. La Pièce 16, Switzerland by its Authorized Representative:

Centraline
Honeywell GmbH
Böblinger Strasse 17
71101 Schönaich, Germany
phone: +49 7031 637 845
fax: +49 7031 637 740
info@centraline.com
www.centraline.com

Printed in Germany.
Subject to change
without notice.
MU1Z-0962GE51 R0710A

